



Product Code: P006AB

Introduction:

This item incorporates several safety features such as automatic thermal cutoff and automatic overload cutoff.

Technical data:

Input: 100-240 V~ 60/50 Hz 185 mA

Output: 12 V $\overline{\text{---}}$ 1000 mA

Output power: 12 VA

Instructions:

1. Please read the following instructions step-by-step before using the adaptor.
2. VOLTAGE: Verify the V requirement of the electronic appliances and determine if it can be used with a 12 V adaptor.
3. MILLIAMPS (mA): Verify the mA requirement of the electronic appliances and determine if it can be used with a 1000 mA adaptor.
4. POLARITY: Determine the polarity (+ or -) of the unit. The polarity can be found on the unit or in the user manual.



5. Output plug: Plug into the jack on the electrical appliance.
6. Insert the input plug of the appliance into the cigarette lighter socket.
7. Attach the Adaptor into a 100-240 V mains socket. The red LED light indicates that the unit is on.
8. Remove the unit from the mains when not in use.

Warning:

1. For indoor use only.
2. The socket-outlet must be installed near the equipment and should be easily accessible.

Distributed by Electrovision Ltd

Lancots Lane, Sutton Oak, St. Helens, Merseyside, WA9 3EX
www.electrovision.co.uk