



# **JB703/JB703A/JB703B/ JB703C/JB703D**



## **Guitar Amplifier**

## **USER MANUAL**

These instructions should be read carefully and left with the user of the product for future reference

### **BEFORE USE**

Inspect the product for any signs of damage. If the product is damaged, DO NOT use it, and contact your supplier immediately

## PRODUCT SAFETY

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Do not use in close proximity to gas appliances.
- Do not cover when in use.
- Do not place the mains lead beneath a carpet or rug.
- Do not use the appliance in locations where paint, petrol or other flammable liquids are used or stored.
- Do not insert any object into the appliance through the back. This may damage the appliance or result in electric shock.
- Do not use this appliance in the immediate surroundings of a bath, a shower or a swimming pool.
- Disconnect the product from the mains when not in use.
- The product should be positioned on firm level ground before use.
- This unit is for indoor use only.
- There are no user serviceable parts in this product.
- Do not allow the product to left switched on

## FUNCTIONS

MP3: Acts as an auxiliary input allowing connection of devices such as MP3 player etc. via a 3.5mm jack socket.

Input: Allows the connection of a guitar or similar instrument via a 6.35mm jack socket

Drive: Causes a distortion effect when pressed

Gain: Increases the distortion effect

Bass: Increases the amount of bass (low frequencies)

Treble: Increases the amount of treble (high frequencies)

Volume: Increases the overall sound volume of the product.

Headphone: Allows connection of a headphone via 6.35mm jack socket.

Power: Switches the power on or off

## USE

Before switching on

- 1) Make sure the volume is turned down.
- 2) Connect your instrument to the unit.
- 3) Turn on the unit using the power switch
- 4) Slowly turn the volume control up to the required level

## SPECIFICATIONS

Size.....	275x280x105mm
Net Weight.....	3kg
Power .....	20W
Voltage.....	230Vac @ 50Hz



Electrovision Ltd.,  
Lancots Lane, Sutton,  
St. Helens, Merseyside.  
WA9 3EX

website: [www.electrovision.co.uk](http://www.electrovision.co.uk)