



G017KG
4-Way LED Disco
POD Light with
Sound to Light
Function



G017KE
6-Way LED Disco
POD Light with
Sound to Light
Function

Instruction Manual

IMPORTANT

Installer and Users please note:

These instructions should be read carefully and left with the user of the product for future reference.

BEFORE USE

You must inspect this product and its power supply before use for any signs of damage. If the products or its lead are damaged in anyway, DO NOT use it, and contact your supplier immediately.

PRODUCT SAFETY

- Only use on flat stable surfaces
- Do not look directly into the beams.
- For indoor use only
- Do not use in bathrooms, or in wet or damp locations.
- Not suitable for people with photo sensitive epilepsy or similar conditions.
- Only use with the included power supply.
- Do not leave this product switched on when not attended.
- The power supply should be switched off and disconnected from the mains when not in use.

OPERATION

Connect each pod to the central controller via the DC sockets on the back of the units. Connect the power supply to an appropriate wall or socket and the lead to the power input on the reverse of the unit.

Switch the unit on or off via the button on the front of the product

Music (Sensitivity) Control: Controls the sensitivity of the built in microphone

Speed Control: Increases the rate of response of the sound to light function.

Adjust these two rotary knobs to achieve the desired effect.

MAINTENANCE

Always disconnect the units from its power supply before cleaning

Cleaning:

Clean the outside of the units with a soft damp cloth, with a drop of washing-up liquid. Dust can be removed by using a small paint brush or similar.

FAULT-FINDING

Lights do not come on:

Check the unit is switched on via the switch on the front of the unit and also that the unit is attached to the mains via the PSU supplied.

DISPOSAL AND RECYCLING

You must not dispose of this appliance with domestic household waste.

Most local authorities have specific collection system for appliances and disposal is free of charge to the end-user.

When replacing an existing appliance with a similar new appliance your retailer may take the old appliance for disposal.

TECHNICAL SPECIFICATION

G017KG 4 Way Pod

Weight:	1.13kg
Dims:	350x240x160mm
PSU Input	230V 0.4A
PSU Output	12V DC 1A
Light Source	LED
Light Control.....	Auto/Sound to Light

G017KE 6 Way Pod

Weight	1.7Kg
Dims	350x350x160mm
PSU Input	230V 0.4A
PSU Output	12V DC 1A
Light Source	LED
Light Control.....	Auto/Sound to Light

SERVICE WARRANTY

Electrovision guarantees the product free from defects in materials and workmanship for a period of one year.

Should this unit be operated under conditions other than those recommended, at voltages other than the voltage indicated on the unit, or any attempts made to service or modify the unit, then the warranty will be rendered void.

The product you buy may sometimes differ slightly from illustrations. This warranty is in addition to, and does not affect, your statutory rights.

If you have any problems with this product, please call our Help Desk on (0845) 459 4816. The help desk is open from 8 am until 1 pm.

Electrovision Ltd.,
Lancots Lane, Sutton,
St. Helens, Merseyside.
WA9 3EX

website: www.electrovision.co.uk