



GH633

BBQ Thermometer



User Manual

Please retain for future reference

IMPORTANT

Installer and users please note:

Please read the entire instruction manual before using the product and then save it for future reference. We reserve the right for any errors in text or images and any necessary changes made to technical data.

PRODUCT SAFETY

- **WARNING:** Choking hazard. Small parts. Keep away from children and pets
- **CAUTION:** Temperature probe will be hot after use, handle with care.
- Children shall not play with the unit.
- Cleaning and maintenance shall not be made by children without supervision.
- Do not use the thermometer for anything other than its intended use.

USAGE INSTRUCTIONS

1. Thoroughly clean the stem of the probe before and after each use with food.
2. Insert the probe as required into the food, leave for 30 seconds and read the temperature from the dial.
3. The clip on the stem may be used to fix the thermometer in place while taking a reading
4. When finished, carefully remove and allow time to cool before cleaning.

CLEANING INSTRUCTIONS

The thermometer should be cleaned periodically and before and after each use with warm water and, if necessary, mild detergent.

STORAGE INSTRUCTIONS

Clean the thermometer, rinse with clean water and allow to fully dry before storing. Store in a cool, dry place.

SERVICE WARRANTY

Electrovision guarantees the product free from defects in materials and workmanship for a period of 1 year. Should this unit be used under conditions other than those recommended, or any attempts made to service or modify the unit, then the warranty will be rendered void. The product you buy may sometimes differ slightly from illustrations. This warranty is in addition to, and does not affect, your statutory rights. If you have any problems with this product, please call our help desk on (0845) 459 4816.