



G009MT

1m (2x 500mm) RGB USB

TV Mood Light



CONGRATULATIONS ON YOUR PURCHASE

Thank you for purchasing this Eagle Tape Light Kit. Please read these instructions carefully and leave with the user of the product for future reference. If the product is sold on then the instruction/manual should pass on as well.

BEFORE USE

You must inspect the product and all accessories including any cables or leads for any signs of damage. If the product is damaged, DO NOT use it, and contact your supplier immediately.

PRODUCT SAFETY


- Children shall not play with the unit.
- Cleaning and user maintenance shall not be made by children without supervision.
- Disconnect from its power supply when not in use
- Do not leave this device switched on when unattended.
- Keep away from moisture and sources of heat.
- For indoor use only.
- Periodically check this product for damage. If any is detected do not use and contact your supplier.
- Only use this product with 5V approved USB outputs (not provided) Rated at 0.2A (1W) or above.

OPERATION and INSTALLATION

- Installation must take place whilst the unit is unplugged
- The product MUST NOT be mounted using staples, nails, or metal fixings.
- The product can be installed in the desired location simply by removing the self-adhesive backing on the rear of the tape light and then pressing the tape light against a smooth clean surface. The surface must be free of dust and grease.
- Apply firm pressure along the length of the tape light to ensure it has adhered in all locations.
- Once installed, plug the product into its USB power supply (not supplied) and switch on.
- Ensure the product is switched off when not in use.

CONTROL

- 3 buttons marked
1. Mode/ Demo
 2. Speed/ brightness /on-off
 3. Speed



- Pressing Button 1 enables selection of 20 Different Static colours
- Pressing Button 2 once will switch the light on pressing it again for 3 seconds will turn the light off
- Pressing Button 2 when in Static Colour Mode will give 5 different level of brightness
- Pressing button 2 when in Dynamic Mode will give 5 different speeds
- Pressing button 3 enables selection of 19 different modes

MAINTENANCE

There are no user serviceable parts in this product. Periodically check the product for LED failure and damage. If any of the LED's have failed or the product is damaged in anyway switch off and disconnect from the mains supply. To clean the product, switch off and disconnect from the mains supply. Using a slightly damp cloth gently wipe over. Do not use bleach, solvent based cleaners or strong detergents. These may damage the product and invalidate the warranty. If the mains lead is damaged, it must be replaced by the manufacturer or and authorised service centre.

Tape Dimensions:2.8 x 10 x 1000mm (2 x 500mm)
Weight:0.1kg
Input:5V via USB
Power Consumption 0.2A (1W)

SERVICE WARRANTY

Electrovision Ltd. guarantees the product free from defects in materials and workmanship for a period of twelve months. Should this product be operated under conditions other than those recommended, or any attempts are made to service or modify the product, then the warranty will be rendered void. The product you buy may sometimes differ slightly from illustrations. This warranty is in addition to, and does not affect, your statutory rights. Our guarantee is administered by our retailers. If your product arrives damaged, you must contact the retailer from whom you bought it. The retailer's contact details will be on the invoice that arrived with the product, or on the e-mail you received when you placed the order. Do not contact Electrovision, only your retailer can arrange a replacement. If the product needs to be repaired or replaced, you must contact the retailer from whom you bought it. If you have just received your product and require technical help in using it, please call our Help Desk on (0845) 459 4816

Electrovision Ltd
Lancots Lane
Sutton, St. Helens
Merseyside
WA9 3EX
www.electrovision.co.uk