



Product Manual for GH252 Outdoor/Indoor String Light 20m

Thank you for choosing one of our festive products. We hope it adds an extra sparkle to your festivities.

This manual forms part of the product and should be kept with the unit at all times. If the product is sold on then the manual should be included.

SAFETY

1. This appliance can be used by children aged 8 years and above, as well as persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, provided they have been given supervision or instruction on using the product safely and understand the hazards involved.
2. Children should not play with this product.
3. Cleaning and user maintenance should not be done by children without supervision.
4. Do not site the power supply in bathrooms, wet rooms, or other damp locations.
5. Do not use the power supply in areas where paint, petrol, or other flammable liquids are used or stored.
6. Always switch off and unplug the power supply when not in use.
7. Use the power supply only with this String lights, which is for decorative purposes only.
8. Before each use, check the String Light and its power supply for any signs of damage. If any damage is detected, stop using it immediately and consult your supplier.
9. Do not leave the power supply switched on when unattended.
10. This product is designed for domestic use only and is not suitable for commercial applications.
11. There are no user-serviceable parts inside the product. If repairs are needed, contact a qualified service centre.
12. Keep children under the age of 8 years away from the String Light unless continuously supervised.
13. Exercise caution when installing or fitting the String Light to avoid accidents.
14. While the String Light itself is water-resistant, the power supply is not. Always keep the power supply indoors and away from water. If necessary, you can use a waterproof power box with a rating of at least IP68 to protect the power supply from water exposure.

HOW TO USE

1. Find a suitable place to install your string lights, such as a porch roof or ceiling.
2. Use a suitable fixing (not supplied) securely attach the string light to the chosen location.
3. Run the power supply cable indoors from the String Light to the controller. Make sure the cable is positioned safely to avoid becoming a tripping hazards.
4. Attach the cable to the power supply and plug the power supply into a standard UK socket. Switch on at the mains.
5. Use the control button on the front of the power supply to set the chosen pattern.

Cleaning and Maintenance

1. Always switch off and unplug the string light before cleaning or performing any maintenance.
2. Clean the String light using a soft, dry cloth. Avoid using abrasive or corrosive cleaning agents.
3. Regularly inspect the power supply cable and power supply for any damage. If any issues are detected, discontinue use until the problem is resolved.
4. Store the String Light in a cool, dry place when not in use to prolong its lifespan.

Specification

Power: 230Vac to 3Vdc PSU

LED: 200 Super Bright

Electrovision Ltd, Lancots Lane, St. Helens Merseyside, WA9 3EX sales@electrovision.co.uk

