




## EH1478

### Prem-i-air Wall Mount Dehumidifier



## User Manual

### Please Retain for Future Reference



Name: Prem-i-air Appliances Ltd.  
E-mail: sales@prem-i-air.co.uk



Name: Aidapt B.V.  
E-mail: nederland@aidapt.eu

AUG 2025

Thank you for buying your Prem-i-air wall-mount dehumidifier. Before use, check the product for damage. If any is detected do not use and contact your supplier.

## **INTENDED USE**

For use as a domestic dehumidifier.

## **INSTRUCTIONS**

This manual forms part of the product and should be kept with the unit at all times. Should the unit be sold or moved on then the manual must be included.

Please read these instructions carefully before use.

This product and its power supply must be checked before use for any signs of damage. If any is detected then do not use and contact your supplier.



## **SAFETY**

- The product and its power supply must be checked before use for any signs of damage, if any is detected do not use and contact your supplier.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- For indoor use only.
- Do not use in bathrooms, swimming pools, shower rooms or other such locations.
- Do not place the mains lead beneath a carpet or rug.
- Do not use this appliance in locations where paint, petrol or other flammable liquids are used or stored.
- Ensure the appliance is switched off and unplugged when not in use.
- Do not use the appliance for other than its intended use.
- Do not insert any object into the appliance through the grilles.
- Periodically check this product and its mains lead for any signs of damage.
- Only use this product on a flat, stable surface.
- Do not leave this product unattended when in use.
- There are no user serviceable parts in this product.
- Do not move or knock this product while in use.
- Do not obstruct the air intakes or exhaust vents.
- This product must only be used in an upright position.
- Do not cover.
- Do not use in areas with high concentrations of dust or fibre particles.
- Water should be removed from the unit each day.
- Do not store with water in the tank.
- This product is designed for a 230V AC, 50Hz power supply via plug in PSU.
- Maintain a minimum clearance of 30cm (12 inches) around all sides.
- Do not immerse the unit in water or allow water to enter the unit (tank excepted).
- Turn off and unplug before emptying.
- Avoid placing the unit near heat sources such as radiators, ovens, or direct sunlight.
- Care should be taken when fitting this product.


# IN THE BOX

- 1 x EH1478 Dehumidifier
- 1 x Power Cord
- 1 x User Manual

## PARTS EXPLAINED



1. Power button
2. Humidity button
3. High and low speed buttons
4. Digital display
5. Work indicator
6. Water full indicator
7. High-speed indicator light
8. Low speed indicator
9. Humidity indicator
10. Hanging board
11. Screw Holes (5)
12. Mount points (4)
13. Air outlet
14. Air inlet
15. DC power socket
16. Removable water tank
17. DC Connector
18. AC to DC Power



## OPERATION

1. Connect the unit to the DC power supply and plug into a UK Mains socket. Briefly press the power button to enter the powered-on state, the fan rotates at high speed by default and the digital display shows the current environmental humidity value. The “ON” indicator, high-speed indicator, and humidity indicator (RH) light up in blue at the same time (see fig.1)
2. Press the humidity button to set the humidity value, each time you press this the humidity value adds 5%; when the set humidity value is greater than the ambient humidity level, the machine will stop dehumidification; press the shutdown button to maintain the last set humidity value.
3. The fan runs at high speed by default, and the high-speed indicator lights up in blue. Press the high-low speed button, the fan will run at low speed, and the low-speed indicator lights up in blue and the high-speed indicator light turns off (see fig.2)
4. When the water tank is full or drawn out, the “ON” indicator flashes, and the water full indicator lights up in red (see fig.3). Disconnect from the power. Carefully remove the full water tank and discard the contents down a sink or similar. Replace the tank and reconnect
5. Load the empty water tank into the machine body to resume normal operation.

fig. 1



fig. 2



fig. 3



## MAINTENANCE AND CLEANING

- There are no user serviceable parts in this product. Any maintenance must be carried out by a qualified and approved supplier.
- The item must be switched off and disconnected from the mains before cleaning and emptying.
- Clean with a slightly damp cloth.
- Dust and debris can be removed using a soft bristle brush.

## SPECIFICATIONS

Voltage .....	13Vdc Via PSU (230V in 13V Out)
Rated Power .....	41.6W
Water Tank Capacity .....	2L
Dehumidifier Dimensions .....	L250 x W110 x H280 mm
Dehumidification Capacity.....	500ml/day (under condition of 30°C and RH80%)



## CONTACT INFORMATION

Prem-i-air Appliances Ltd, Lancots Lane, Sutton, St. Helens, WA9 3EX  
[sales@prem-i-air.co.uk](mailto:sales@prem-i-air.co.uk)



Name: Prem-i-Air Appliances Ltd.  
E-mail: [sales@prem-i-air.co.uk](mailto:sales@prem-i-air.co.uk)

EC REP

Name: Aidapt B.V.  
E-mail: [nederland@aidapt.eu](mailto:nederland@aidapt.eu)

AUG 2025