



E804A (Red)  
E804AB (Black)  
E804AC (Orange)

## Eagle IP44 Electrical Connection Box

### IMPORTANT

Installers and Users please note:

These instructions should be read carefully before use and this document constitutes part of the product which should be kept safely by the user alongside the product

### INTENDED USE ONLY

This product is designed to protect a single plug and socket connection.

Do not attempt to modify or use it for other purposes.

### BEFORE USE

You must inspect the box for any signs of damage. If the product is damaged, DO NOT use it, and contact your supplier immediately

### PRODUCT SAFETY

Not designed for permanent installation

**IP44 Splashproof Rating:** The safe box is suitable for use in sheltered outdoor areas. It protects against splashes of water but must not be submerged or exposed to high-pressure water jets.

**Dry Hands Only:** Always connect and disconnect plugs with dry hands.

**Do Not Overload:** Ensure that the connected devices do not exceed the rated current of your extension lead and socket.

**Avoid Loose Connections:** Fully insert plugs and sockets inside the box to prevent arcing or overheating.

**Protection Against Electric Shock:** The safe box helps reduce risks but does not replace proper electrical safety measures. Always use a residual current device (RCD) when operating outdoors

**Avoid Pinching Cables:** Ensure cables are routed through entry holes without being pinched or bent sharply.

**Indoor & Outdoor Applications:** Suitable for use in the garden, camping, caravans, and with household power tools. Do not use in extreme conditions (heavy rainstorms, snow, or direct submersion).

**Storage:** Disconnect and store the unit in a dry place when not in use for extended periods.

**In Case of Damage:** Disconnect immediately from the mains power supply if water enters the unit or if it becomes damaged. Do not attempt to repair.

### HOW TO USE

1. Release the clips on the side of the box and open the front cover of the box
2. Place the required connections inside the box and lie the cables in the cable tracks
3. Close and lock the cover

### SERVICE WARRANTY

Eagle guarantees the product free from defects in materials and workmanship for a period of twelve months. Should this box be operated under conditions other than those recommended or any attempts made to service or modify the box, then the warranty will be rendered void. The product you buy may sometimes differ slightly from illustrations. This warranty is in addition to, and does not affect, your statutory rights. Our guarantee is administered by our retailers. If your product arrives damaged, you must contact the retailer from whom you bought it. The retailer's contact details will be on the invoice that arrived with the product, or on the e-mail you received when you placed the order. Do not contact Eagle, only your retailer can arrange a replacement. If the product needs to be repaired or replaced, you must contact the retailer from whom you bought it. If you have just received your product and require technical help using it, please call our Help Desk on (0845) 459 4816 If you have any other technical queries about the product, please call our Help Desk on (0845) 459 4816



**Name:** Electrovision Ltd.

**Address:** Lancots Lane, Sutton Oak, St. Helens, WA9 3EX

**Tel:** 01744 745 000 | **E-mail:** sales@electrovision.co.uk



**Name:** Aidapt B.V.

**Address:** Algouvwxyz 22, Amersfoort, 3821BH, NL

**Tel:** +31 0332779210 | **E-mail:** nederland@aidapt.eu

