



100W T2 Ceiling Rose

Installation Instructions

IMPORTANT

Installer and Users please note: Installation of this item should only be attempted by a competent professional.

BEFORE USE

You must inspect the item for any signs of damage. If the product is damaged, DO NOT use it, and contact your supplier immediately.

PRODUCT SAFETY

- For indoor use only.
- Do not use the item for other than its intended use.
- Observe the maximum rating for the item.
- Before use read these instructions carefully and use in accordance with these safety instructions
- Before commencing and electrical work ensure the supply is **switched off at the mains**. Either by switching off at the consumer unit or by removing the appropriate fuse.
- Wiring should be in accordance with latest edition of the IEE regulations (BS7671).

Wire Identification – Twin & Earth Cable

EARTH = Green/Yellow Sleevings

NEUTRAL = Black or Blue

LIVE = Red or Brown



The ends of the individual conductors should have the insulation removed by approx. 12mm. Any bare earth conductors should be sleeved to 12mm from the end. All measurements are for guidance only and may vary according to the relevant installation.

HOW TO USE

If replacing an existing ceiling rose.

1. If at any point you have any doubts about installing this item then STOP and consult a competent professional.
2. Inspect the item for any damage, if damaged DO NOT USE.
3. This item is designed to take a standard UK bayonet type (B22D) fitting and can take a maximum load of 100W.
4. Switch off the Mains supply at the Fuse Board
5. Remove the existing ceiling rose taking care to mark and note down the existing wiring layout.
6. Prepare the cable ready for use.
7. Unscrew the ceiling rose cover from the base.
8. Fix the base to the ceiling using appropriate fixings ensuring the cable entry point is free of sharp edges.
9. The ceiling rose has a number of connector blocks for the loop live in/out (centre block) as well as the neutral and switched live connections which are marked accordingly. Care must be taken to transfer the wiring from the old rose to the new.
10. The ceiling rose does not require an earth and is doubly insulated but a terminal is supplied to be able a loop in and out of the earth cable. All bare earth wire should be sheathed.
11. Once wiring is complete the cover can be screwed back onto the base.
12. Once the work has been completed correctly replace / switch on the fuse for the circuit and switch the power back on then test.

If fitting a new ceiling rose.

1. If at any point you have any doubts about installing this item then STOP and consult a competent professional.
2. Inspect the item for any damage, if damaged DO NOT USE.
3. This item is designed to take a standard UK bayonet type (B22D) fitting and can take a maximum load of 100W.
4. Switch off the Mains supply at the Fuse Board
5. Prepare the cable ready for use.
6. Unscrew the ceiling rose cover from the base.
7. Fix the base to the ceiling using appropriate fixings ensuring the cable entry point is free of sharp edges.
8. The ceiling rose has a number of connector blocks for the loop live in/out (centre block) as well as the neutral and switched live connections which are marked accordingly. Care must be taken to transfer the wiring from the old rose to the new.
9. The ceiling rose does not require an earth and is doubly insulated but a terminal is supplied to be able a loop in and out of the earth cable. All bare earth wire should be sheathed.
10. Once wiring is complete the cover can be screwed back onto the base.
11. Once the work has been completed correctly replace / switch on the fuse for the circuit and switch the power back on then test.

GENERAL SAFETY REQUIREMENTS

Domestic wiring must be tested periodically by a qualified electrician at least once every 10 years or at every change of occupancy. For office and retail premises (and buildings such as village halls) the wiring must be inspected at least once every 5 years. It is recommended that all buildings be fitted with smoke alarms (it is mandatory for new buildings).

CHANGES TO BUILDING REGULATIONS – IMPORTANT!

As from 1 January 2005, any electrical work done in domestic, fixed wiring installations in England and Wales, will have to follow new rules & changes to the Building Regulations Part P. These rules have been introduced to help reduce the number of deaths, injuries and fires caused by faulty installations. The installation work may be carried out by anyone providing it is in accordance with the Regulation standards. Certain electrical work (non-notifiable or minor work) may be carried out without having to use a registered electrician or notify Local Authority Building Control, such as:

- replacing any electrical fitting (for example, socket outlets, light fittings, control switches)
- adding fused spurs, sockets or lights to an existing circuit (but not in a kitchen, bathroom or outdoors)
- any repair or maintenance work

For minor work done by a non-qualified electrician, it is highly recommended it is checked by a qualified electrician to ensure it is safe.

For all other work (notifiable or major work) a Building Regulations application is required & it must be checked to make sure it is safe.

This may be done by either an electrician who is part of a competent person self-certification scheme, or by notifying the Local Authority Building Control Department who will make required arrangements.

An application must be made to the Local Authority before commencing work such as: -

- adding a new circuit
- adding/altering any circuit in a room with water (kitchen, bathroom, etc)
- adding/altering any circuit outdoors (outdoor sockets, lights, etc)

Where work is done by a qualified electrician, they will be responsible for checking the work and the Local Authority does not need notification.

Where a qualified electrician or Local Authority is responsible for checking the work, they will provide a certificate or notice to confirm that the installation is tested & safe to use.

IT IS RECOMMENDED TO USE A QUALIFIED ELECTRICIAN

If there is any doubt whether electrical work needs notification of the Local Authority, they should be contacted first for advice.

CABLE INSTALLATION METHODS AND SIZES

The current carrying capacity of any cable is dependent on the installation and then the voltage loss that may be experienced over the length of the cable run. The installation methods are listed below and the table following shows the current carrying capacity of the differing cables sizes for each method along with the voltage drop that would occur per meter for each cable type.

Method A – Enclosed in conduit in an insulated wall

Method B – Enclosed in conduit or trunking on a wall

Method C – Clipped direct

Method 100 – In contact with plasterboard, ceiling or joists, covered by thermal insulation not exceeding 100mm

Method 101 – In contact with plasterboard, ceiling or joists, covered by thermal insulation exceeding 100mm

Method 102 – In a stud wall with thermal insulation with cable touching the wall

Method 103 – Surrounded by thermal insulation including in a stud wall with thermal insulation with cable not touching the wall

Conductor (Cable Size Guide) & Max Load							
Installer Method	1.0mm ²	1.5mm ²	2.5mm ²	4.0mm ²	6.0mm ²	10.0mm ²	16.0mm ²
Method A	11.5A	14.5A	20A	26A	32A	44A	57A
Method B	13A	16.5A	23A	30A	38A	52A	69A
Method C	16A	20A	27A	37A	47A	64A	85A
Method 100	13A	16A	21A	27A	34A	45A	57A
Method 101	10.5A	13A	17A	22A	27A	36A	46A
Method 102	13A	16A	21A	27A	35A	47A	63A
Method 103	8A	10A	13.5A	17.5A	23.5A	32A	42.5A
Voltage Drop (mV/A/m)	44	29	18	11	7.3	4.4	2.8

SERVICE WARRANTY

- Eagle guarantees the product free from defects in materials and workmanship for a period of twelve months.
- Should this item be operated under conditions other than those recommended, at voltages other than the voltage indicated on the item, or any attempts made to service or modify the item, then the warranty will be rendered void.
- The product you buy may sometimes differ slightly from illustrations. This warranty is in addition to, and does not affect, your statutory rights.
- Our guarantee is administered by our retailers.
- If your product arrives damaged, you must contact the retailer from whom you bought it. The retailer's contact details will be on the invoice that arrived with the product, or on the e-mail you received when you placed the order. Do not contact Eagle, only your retailer can arrange a replacement.
- If the product needs to be repaired or replaced, you must contact the retailer from whom you bought it.
- If you have just received your product and require technical help using it, please call our Help Desk on (0845) 459 4816
- If you have any other technical queries about the product, please call our Help Desk on (0845) 459 4816

Electrovision Ltd.
Lancots Lane, Sutton
St. Helens, Merseyside
WA9 3EX
www.electrovision.co.uk