



**EH5798**

Prem-I-Air 16" (40 cm) White Oscillating Desktop Fan  
with 3 Speed Settings



**User Manual**  
Please Retain for Future Reference

## INTENDED USE

For use as a domestic cooling fan

## INSTRUCTIONS


This manual forms part of the product and should be kept with the unit at all times. Should the unit be sold or moved on then the manual must be included.

## PRODUCT SAFETY

- Please read these instructions carefully before use. This product and its mains lead must be checked before use for any signs of damage. If any is detected then do not use and contact your supplier.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- For indoor use only.
- Do not use in bathrooms, swimming pools, shower rooms or other such locations
- Do not place the mains lead beneath a carpet or rug.
- Do not use this appliance in locations where paint, petrol or other flammable liquids are used or stored.
- Please ensure the appliance is switched off and unplugged when not in use.
- Do not use the appliance for anything other than its intended use.
- Do not insert any object into the appliance through the grilles. This may damage the product or result in overheating or electric shock.
- Periodically check this product and its mains lead for any signs of damage. If any damage is detected stop using it immediately and consult your supplier.
- Only use this product on a flat, stable surface.
- Do not leave this product unattended when in use.
- There are no user serviceable parts in this product
- Do not move or knock this product while in use.
- Do not obstruct the air intakes or exhaust vents
- This product must only be used in an upright position.
- Do Not Cover
- Do not use in areas with high concentrations of dust or fibre particles.
- This product is designed for a 230V AC, 50Hz power supply. Connecting to an incorrect power supply can cause electrical shock or fire.
- Maintain a minimum clearance of 30cm (12 inches) around all sides for adequate airflow.
- This is an electrically powered device. Do not immerse in water or allow water to enter the unit.
- Avoid placing the unit near heat sources such as radiators, ovens, or direct sunlight.
- Care should be taken when fitting this product

## IDENTIFICATION OF PARTS

1. Front Grille
2. Blade Nut
3. Fan Blade
4. Guard Mount Nut
5. Rear Grille
6. Motor Shaft
7. Motor Housing
8. Oscillation Control Knob
9. Stand
10. Speed Selection Switches
11. Fan Base
12. Screws



## ASSEMBLY

1. Insert the fan into the base (11) and insert screws (12) in underside to attach
2. Loosen the guard mount nut (4) from the motor housing (7)
3. Attach the rear grille (5) to the motor housing (7)
4. Secure the rear guard by attaching the guard mount nut (4) and turning tightly clockwise
5. Attach the fan blade (3) to the motor shaft (6) and fasten by turning the fan blade (3) tightly **anti-clockwise**
6. Place the front grille (1) on the rear grille (5), aligning the small screw holes on each grille, and secure using the clips attached to the front grille (1)
7. Secure the 2 grilles by inserting the small screw into the hole at the bottom of the grilles and attaching the supplied nut

## OPERATION

- Plug the mains lead into a 13 Amp mains socket.
- If connecting via an extension lead, make sure that the lead is rated at 3 Amps or more, and that it is fully unwound.
- Switch the appliance on at the mains socket.
- Use the push-button switches to the speed required. 0=OFF, 1=LOW SPEED, 2=MEDIUM SPEED, 3=HIGH SPEED
- Oscillation is selected by pressing the oscillation control knob (8) downwards and switched off by pulling it upwards
- It is normal for the motor to become warm in normal use.
- Unplug the appliance from the mains when not in use.

## OPERATING COSTS

At time of going to press, the average cost of electricity is £0.26 per unit (kilowatt-hour). The amount you are being charged will be shown on your electricity bill. At this cost, the EH5798 will cost 28p per day to run on the highest setting.

## PAT TESTING

When used in an office environment, this product must be safety-tested yearly by a qualified electrician (PAT Tested) in order to comply with the Electricity at Work Regulations.

We recommend that it is PAT tested regularly when used in a domestic environment.

## GENERAL SAFETY REQUIREMENTS


Domestic wiring must be tested periodically by a qualified electrician at least once every 10 years or at every change of occupancy.

For office and retail premises, and buildings such as village halls, the wiring must be inspected at least once every 5 years. It is recommended that all building be fitted with smoke alarms (it is mandatory for new buildings).

## MAINTENANCE

Before cleaning, turn the appliance off, and disconnect from the mains supply. The appliance may then be cleaned using a damp cloth with a drop of washing-up liquid to remove any dust or dirt from the case. Do not use stronger detergents or solvents as these may damage the paint finish.

Using a dry 1" (25 mm) paint-brush, remove any dust from the grilles.



If the mains lead is damaged, it must be replaced by the manufacturer or an authorised service centre.

If the mains plug needs to be replaced, proceed as follows;

- Connect the brown wire to the terminal labelled "L".
- Connect the blue wire to the terminal labelled "N".
- Make sure that the cord-grip is positioned correctly (over the outer sheath of the cable) and it is fully tightened.

## DISPOSAL AND RECYCLING

You must not dispose of this appliance with domestic household waste.

Most local authorities have specific collection system for appliances and disposal is free of charge to the end-user.

When replacing an existing appliance with a similar new appliance your retailer may take the old appliance for disposal.

## TECHNICAL SPECIFICATION

Dimensions:.....570x460x240mm  
Weight:.....2.6kg  
Power Supply:.....230V~  
Power Consumption:.....45W (max)  
Air Flow:.....3355 m3/h (max)

Operating Current:.....0.2A  
Air Speed:.....2.46 m/s  
Noise:.....58.3 dBA  
Service Value:.....1.30 m3/W.min

## SERVICE WARRANTY

Prem-i-Air guarantees the product free from defects in materials and workmanship for a period of 2 years.

Should this appliance be operated under conditions other than those recommended, at voltages other than the voltage indicated on the appliance, or any attempts made to service or modify the appliance, then the warranty will be rendered void. The product you buy may sometimes differ slightly from illustrations. This warranty is in addition to, and does not affect, your statutory rights.

If you have any problems with this product, please call our Help Desk on **(0845) 459 4816**.

### Manufacturer/Importer

Name: Prem-i-Air Appliances Ltd.

Address: Lancots Lane, Sutton Oak, St. Helens, WA9 3EX

Tel: 01744 745 030

E-mail: sales@prem-i-air.co.uk

### EU Authorised Representative

Name: Aidapt B.V.

Address: Algolweg 22,

Amersfoort, 3821BH, NL

Tel: +31 0332779210

E-mail: nederland@aidapt.eu

