



EH5522

Prem-I-Air 12" (30cm) White Oscillating Desktop Fan
with 3 Speed Settings



User Manual
Please Retain for Future Reference

IMPORTANT

Installer and Users please note:

These instructions should be read carefully and left with the user of the product for future reference.

The product and its mains lead should be inspected before use for signs of damage.

Do not use if there are any signs of damage, and consult your supplier for advice.

BEFORE USE

You must inspect the appliance including its cable and plug for any signs of damage. If the product is damaged, DO NOT use it, and contact your supplier immediately.

INTENDED USE


Designed to be used as a domestic fan

PRODUCT SAFETY

- For indoor use only
- Only use this product on a flat stable surface
- Do not leave this product unattended when in use
- Leave at least 50cm gap around the product to allow for airflow
- Disconnect from the mains supply when not in use.
- Do not use in areas of high dust or particle concentration: Risk of explosion
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Do not use in close proximity to gas appliances
- Do not use unless correctly installed.
- Do not cover when in use.
- Do not place the mains lead beneath a carpet or rug.
- Do not use the appliance in locations where paint, petrol or other flammable liquids are used or stored.
- Not suitable for use in boats, caravans or other similar areas.
- Do not insert any object into the appliance through the grilles. This may damage the appliance or result in overheating or electric shock.
- Do not use this appliance in the immediate surroundings of a bath, a shower or a swimming pool.
- The appliance is fitted with an overload cut-out which will operate if the motor overheats or is stalled. If this happens, disconnect from the mains supply immediately, and allow the motor to cool down.

IDENTIFICATION OF PARTS

1. Front Grille
2. Blade Nut
3. Fan Blade
4. Guard Mount Nut
5. Rear Grille
6. Motor Shaft
7. Motor Housing
8. Oscillation Control Knob
9. Stand
10. Speed Selection Switches
11. Fan Base
12. Screws



ASSEMBLY

1. Insert the fan into the base (11) and insert screws (12) in underside to attach
2. Loosen the guard mount nut (4) from the motor housing (7)
3. Attach the rear grille (5) to the motor housing (7)
4. Secure the rear grille (5) by attaching the guard mount nut (4) and turning tightly clockwise
5. Attach the fan blade (3) to the motor shaft (6) and fasten by turning the fan blade (3) tightly **anti-clockwise**
6. Place the front grille (1) on the rear grille (5), aligning the small screw holes on each grille, and secure using the clips attached to the front grille (1)
7. Secure the 2 grilles by inserting the small screw into the hole at the bottom of the grilles and attaching the supplied nut

OPERATION

- Plug the mains lead into a 13 Amp mains socket.
- If connecting via an extension lead, make sure that the lead is rated at 3 Amps or more, and that it is fully unwound.
- Switch the appliance on at the mains socket.
- Use the push-button switches to the speed required. 0=OFF, 1=LOW SPEED, 2=MEDIUM SPEED, 3=HIGH SPEED
- Oscillation is selected by pressing the oscillation control knob (8) downwards and switched off by pulling it upwards
- It is normal for the motor to become warm in normal use.
- Unplug the appliance from the mains when not in use.

OPERATING COSTS

At time of going to press, the average cost of electricity is £0.25 per unit (kilowatt-hour). The amount you are being charged will be shown on your electricity bill. At this cost, the EH5522 will cost 24p per day to run on the highest setting.

PAT TESTING

When used in an office environment, this product must be safety-tested yearly by a qualified electrician (PAT Tested) in order to comply with the Electricity at Work Regulations.

We recommend that it is PAT tested regularly when used in a domestic environment.

GENERAL SAFETY REQUIREMENTS


Domestic wiring must be tested periodically by a qualified electrician at least once every 10 years or at every change of occupancy.

For office and retail premises, and buildings such as village halls, the wiring must be inspected at least once every 5 years. It is recommended that all building be fitted with smoke alarms (it is mandatory for new buildings).

MAINTENANCE

Before cleaning, turn the appliance off, and disconnect from the mains supply. The appliance may then be cleaned using a damp cloth with a drop of washing-up liquid to remove any dust or dirt from the grille and case. Do no use stronger detergents or solvents as these may damage the finish.

Using a dry 1"(25 mm) paint-brush, remove any dust from the grilles.



If the mains lead is damaged, it must be replaced by the manufacturer or an authorised service centre.

If the mains plug needs to be replaced, proceed as follows;

- Connect the brown wire to the terminal labelled "L".
- Connect the blue wire to the terminal labelled "N".
- Make sure that the cord-grip is positioned correctly (over the outer sheath of the cable) and it fully tightened.

DISPOSAL AND RECYCLING

You must not dispose of this appliance with domestic household waste.

Most local authorities have specific collection system for appliances and disposal is free of charge to the end-user.

When replacing an existing appliance with a similar new appliance your retailer may take the old appliance for disposal.

TECHNICAL SPECIFICATION

Dimensions:.....	450x280x280mm	Operating Current:.....	0.17A
Weight:.....	2kg	Air Speed:.....	2.43 m/s
Power Supply:.....	230V~	Noise:.....	54.3 dBA
Power Consumption:.....	40W (max)	Service Value:.....	0.87 m ³ /W.min
Air Flow:.....	1894 m ³ /h (max)		

SERVICE WARRANTY

Prem-i-Air guarantees the product free from defects in materials and workmanship for a period of 1 year.

Should this appliance be operated under conditions other than those recommended, at voltages other than the voltage indicated on the appliance, or any attempts made to service or modify the appliance, then the warranty will be rendered void. The product you buy may sometimes differ slightly from illustrations. This warranty is in addition to, and does not affect, your statutory rights.

If you have any problems with this product, please call our Help Desk on **(0845) 459 4816**.



Name: Prem-i-Air Appliances Ltd.

Address: Lancots Lane, Sutton Oak, St. Helens, WA9 3EX

Tel: 01744 745 030 | E-mail: sales@prem-i-air.co.uk



Name: Aidapt B.V.

Address: Algolweg 22, Amersfoort, 3821 BH, NL

Tel: +31 0332779210 | E-mail: nederland@aidapt.eu